



CigaretteBuster™

Cigarette Smoke Detector – Model 4xxx

User Instructions



Congratulations on your purchase of a CigaretteBuster™ Smoke Detector to enforce your smoking rules!

1. Unpack box carefully.
2. Test all parts of your CigaretteBuster™ detector system in one room to ensure that everything has arrived safely and is working properly before installing.
 - For models with remote output, follow procedures on your system's Installation Instructions.
 - For models with internal alarm (4073 and 4250):
 - a. Check that batteries are tightly in place with polarity of battery aligned with polarity on holder (+ to +) (model 4073 only).
 - b. Turn detector ON by sliding black plastic switch in the direction indicated by the label.
3. When you are ready to install, position detector on ceiling centered over common locations for illicit smoking and turn switch ON. If possible, choose a time when no smokers will be around to observe where or how it works.
4. Mount detector by driving the 2 screws into a secure surface on the ceiling, being careful to align them with both the holes in the air vent. Use screwdriver, screws provided, and ladder. For some ceiling surfaces, you may need to drill pilot holes and insert plastic anchors before driving in screws. You may want to add household smoke detectors to camouflage location of detector.
5. Refer to separate Installation Instruction sheets for completing installation of receiver or indicator for wired and wireless system (models 4210, 4230, 4240, 4250).
6. Once installed, test your new smoking detector again to ensure that it is working properly by lighting a cigarette 2 to 4 feet in front of the detector.
 - Models 4073 and 4250 will sound a local alarm.
 - Look and/or listen for indicator remotely with models 4210, 4230, 4240, and 4250.
7. Routine Maintenance will be needed periodically:
 - Inspect detector to ensure that it has not been tampered with and that chamber is free from dirt.
 - Replace batteries annually or if detection is noticeably diminished (models 4073, 4210, and 4230 only). Batteries can be found in many locations.

US Patent 6,545,608

Questions, comments, or concerns:

Voice Products, LLC

23715 Mercantile Road #200, Cleveland OH 44122 USA

phone: 216-360-0433 • fax: 216-360-9805

email: sales@cigarettesmokedetector.com

web: www.cigarettesmokedetector.com

The world leader in smoking rules enforcement!